


SONY : ????????? (????) ??? Sony VAIO VPCSD VPCSB VPCSC VPCSA ????? 4-pin

???????? (????) ??? Sony VAIO VPCSD VPCSB VPCSC VPCSA ?????
4-pin



???????? (????) ??? Sony VAIO VPCSD VPCSB VPCSC VPCSA ????? 4-pin FAN

?????: ??? ???
???
??? 1500,00 ???

[????? ?????? ?? ??????](#)

????????????[SONY](#)

???????

???????? (????) ??? Sony VAIO VPCSD VPCSB VPCSC VPCSA ????? 4-pin FAN

???????????? ??????:

G70N05NS5MT-57T02SVS

MBX-237

???????????? ??????:

Sony VAIO VPCSD VPC-SD

Sony VAIO VPCSB VPC-SB

Sony VAIO VPCSC VPC-SC

Sony VAIO VPCSA VPC-SA

Sony VAIO PCG-41217T

Sony VAIO PCG-41219T

Sony VAIO PCG-41218V